



- J1 - INPUT JACKS
- J2 - CLEAN TB
- J3 - CLEAN VOLUME
- J4 - OD GAIN
- J5 - OD VOLUME
- J6 - FX JACKS
- J7 - FX/MAIN BALANCE
- J8 - OUT
- J9 - HIGH VOLTAGE DC
- J10 - HEATER DC
- J11 - FOOTSWITCH
- J12 - FRONT SWITCHES
- J13 - FRONT SWITCHES
- J14 - LEDS



**BOGNER ECSTASY  
PREAMP PART**